

# How to fill the engine wash cart for temperatures between 41°F and 15.8°F



1. Fill 5 gal. premix container with isopropyl alcohol to ISO line.



2. Take the water hose out.



3. Fill premix container with water to the fill line.



4. Pour contents of premix container into engine wash cart tank.